# How to import a CSV wire labels report (data file) into Rhino

**Step 1:** Open Rhino Software

**Step 2:** From the main menu click on **Import…**

**Step 3:** From the Import Data dialog box click on **Browse…** button

**Step 4:** Search for **C:\Windows\Temp\CSV-TEM.csv** file

**Step 5:** From the Import Data dialog box click on **Import** button

**Step 6:** Now your wire labels are ready to print